

InteliGen^{NT}400Hz 1.6.1

Firmware version for InteliGen^{NT} 400Hz controllers



New Features List

1 General information	2
2 Changes in the version 1.6.1	3
3 Changes in the version 1.6.0	4
4 Related information	5
5 Notes	6



Greenpower AB

Helsingborgsvägen Varalöv
262 96 Ängelholm
Tel: 0431-222 40
Fax: 0431-222 70
E-mail: info@greenpower.se
web : www.greenpower.se

1 General information

1.1 Version information

This is a minor version of IG-NT- 400Hz fw.

This version contains repair of Modbus communication.

1.2 Clarification of notation

Note: This type of paragraph calls readers attention to a notice or related theme.

IMPORTANT: This type of paragraph highlights a procedure, adjustment etc., which can cause a damage or improper function of the equipment if not performed correctly and may not be clear at first sight.

Example: This type of paragraph contains information that is used to illustrate how a specific function works.

2 Changes in the version 1.6.1

2.1 Repairs

- Modbus TCP and Modbus RTU work correctly now.

3 Changes in the version 1.6.0

3.1 New features

- Support of new peripheral modules was added – Peripheral modules:
 - Inteli IO8/8
 - Inteli AIN8
 - Inteli AIN8TC
 - Inteli AIO9/1

are supported with all their features.

4 Related information

4.1 Available files

Firmware (*.mhx)
For IntelliGen 400Hz NTGC and IntelliGen^{NT} BaseBox
IG-NT-400Hz-1.6.1.mhx

Table 4.1 Available firmware

Archives (*.ant)
For IntelliGen 400Hz NTGC and IntelliGen^{NT} BaseBox
IG-NT-400Hz-MINT-1.6.0.ant

Table 4.2 Available archives

4.2 Available related documentation

Documents	Description
IG-NT-MINT-2.6 Reference Guide.pdf	General description of BTB applications for IntelliMains NT . Contains general information about installation and related PC software.
IG/IS-NT Operator Guide 01-2014.pdf	Operator Guide for IntelliGen ^{NT} and IntelliSys ^{NT} controllers.
IG/IS-NT Installation Guide 08-2014.pdf	Thorough description of installation and technical information about IntelliGen ^{NT} , IntelliSys ^{NT} , IntelliMains ^{NT} and related accessories.
IG/IS-NT Communication Guide 09-2014.pdf	Thorough description of connectivity and communication for IntelliGen ^{NT} , IntelliSys ^{NT} , IntelliMains ^{NT} and related accessories.

Table 4.3 Available documentation

5 Notes

5.1 Document history

Revision number	Related sw. version	Date	Author
2	1.6.1	13.5.2013	Ladislav Szetei
1	1.6.0	7.1.2015	Ladislav Szetei